


FAST TRACK SET UP

- 1) At the finish line, attach the timing gate. The numbers should face toward the starting line.




To ease the installation, remove the bolt / nut that holds the bottom brace in place.

There is a small board that goes in between the bottom of the track and the bottom brace of the timer. Make sure that all of the holes are aligned with the sensors in the bottom brace.

- 2) Connect the phone wire between the timer and the start, the power supply and the serial cable to the computer.



3) Attach the laser starter to the left side (looking toward the finish) of the start line. The laser attached by magnets.





Attach the sensor / reset button to the right side using the three small screws to the underside of the track.

4) Connect the wire from the bottom of the laser to the side of the sensor.




And the other end of the telephone wire from the finish line to the sensor.

- 5) Align the laser by pressing the black button on the top of the sensor. The laser must be centered in the white plastic disk for it to work properly. If it aligned properly it will stay lit when the black button is released.

INCORRECT

CORRECT



Everything else is managed by the GrandPrix software.